

Addagrip PPS

Addagrip Porous Paving System

Suggested base build up for light vehicular or pedestrian use.

0.5mm dia grit cast onto uncured surface

6-10mm Addastone TP or
Addaset Resin Bound Gravel

APPS

Surface Course

Hand applied and trowelled
to a smooth finish by
Addagrip approved installers.

Addagrip Porous Paving System
Terram geotextile

20mm depth

Laid up to an edge

Sharp sand, laid to levels
compacted and flat.

Terram 2000
geotextile

75mm depth
CellWeb™ cellular
confinement system
or similar.

20/40mm
open sub-base

Geogrid
if required

Terram 2000
geotextile

Sub-grade

Note:

The minimum 20mm depth of bedding sand should be applied to good levels to allow the Addagrip Porous Paving System to be applied on to a flat and level surface. The Terram 2000 or similar should be installed on top of the CellWeb cellular confinement system and up and around the edges to retain the sand.

Edging:

A suitable edge detail is essential to retain the Addagrip Porous Paving System. This can be achieved by using existing walls, buildings, stone setts, kerbs, timber, metal edging etc. The edging needs to be installed so it is proud of the APPS thus enabling the Addaset to be applied up to a suitable edge.

Laying:

Place the Addagrip Porous Paving System over the prepared and level bedding sand, cutting to shape as required. Apply Addastone TP UV or Addaset Resin Bound Porous Paving as required.

Any advice, recommendation or information given by Addagrip Surface Treatments UK Limited is based on practical experience and is believed to be accurate at the time of publication, no liability or responsibility of any kind (including liability for negligence) is accepted in this respect by the Company, its Servants or Agents. The figures quoted do not constitute a specification they represent typical values obtained for this product.